

Aerosol Can Puncturing



| Document Number: | PKR-PRO-009.003.039 | Reviewed By: | PKR Core Team |
|---------------------|---------------------|--------------|--------------------|
| Effective Date: | 9/6/07 | Approved By: | PKR Executive Team |
| Revision Number: | 0 | Signature: | Paul DOy |

Wear protective goggles to minimize splash hazard Remove the plastic nozzle and discard. Place can top down into puncture unit. Verify contents of the empty can are compatible with the contents of the storage container. Secure can in puncture device by engaging sliding cover plate against can being punctured and secure with screw in side bolt Use lever to engage puncturing tip and wait 20 seconds for pressure to be relieved and can to drain. Dispose of empty punctured can as scrap metal.



Yes – Ensure that appropriate PPE is used



No – Ensure proper compatibility



Yes - Ensure can is properly secured



Yes – Dispose of punctured can as scrap metal